

**Make: MERCEDES-BENZ**

**Model: SPRINTER 2-t Bus**

**Part Number: ADB03311**

**Vehicle Manufacturing/Engine:**



### Specifications

<b>Fitting Position</b>	:	Rear
<b>Model Date</b>	:	2000-2006
<b>Or. Caliper</b>	:	
<b>WVA</b>	:	24739
<b>FMSI</b>	:	
<b>Length</b>	:	
<b>Width</b>	:	
<b>Thickness</b>	:	